

????????????? ??? ?????????? (?????): ???????????? ??? ????????? Acer 3810/5810 10.8?, 5

????????????? ??? ?????????? Acer 3810/5810 10.8?, 5200mAh, [AS09D75)



9813c82777feaa417d6cd2bf54b0a045.jpg

????????????? ??? ?????????? Acer 3810/5810 10.8?, 5200mAh, [AS09D75)

?????????: ??? ???? ??????????
????
???? 2500 ???

[?????? ??????? ?? ???????](#)

?????????

????????????? ?? ?????????????? ?????????? ??????????:

Acer Aspire: 3410, 3410G, 3750, 3750G, 3750Z, 3810T, 3810TG, 3810TZ, 3810TZG, 3811TG, 3811TZ, 3811TZG, 4410, 4810T, 4810TG, 4810TZ, 4810TZG, 5410, 5534, 5538, 5538G, 5810T, 5810TG, 5810TZ, 5810TZG
Acer TravelMate: 8331, 8331G, 8371, 8371G, 8431, 8471, 8471G, 8571
Emachines E: E628
Gateway EC: EC38, EC54, EC58
Gateway NV: NV4TH, NV49C, NV50A, NV51, NV51B, NV51M, NV52, NV53, NV53A, NV55C, NV55S, NV56, NV57H, NV59, NV59C, NV73A, NV79C
Packard bell EasyNote: EN TSX62HR

????????????? ?????? ??????????????:

AS09D31; AK.006BT.027; AK.006BT.068; AS09D34; AS09D36; AS09D41; AS09D51; AS09D56; AS09D70; AS09D71; AS09D73; AS09D75;
AS09D78; AS09D7C; AS09D7D; AS09F34; AS09F56; BT.00603.079; BT.00603.080; BT.00603.082; BT.00603.090; BT.00603.091;
BT.00603.092; BT.00603.099; BT.00603.101; BT.00604.038; BT.00604.039; BT.00605.038; BT.00605.041; BT.00605.048; BT.00605.053;
BT.00605.054; BT.00607.078; BT.00607.079; BT.00607.082; BT.00607.089; BT.00607.090; BT.00607.096; BT.00607.097; BT.00607.098;
BT.00607.099; BT.00607.101; BT.00607.108; BT.00607.109; BT.00607.110