

????????????? ??? ?????????? (?????): ?????????? ??? ????????? Acer Aspire 5741, 5733,

????????????? ??? ????????? Acer Aspire 5741, 5733, 4551, 4741, 4740, 4771



????????????? ??? ????????? Acer Aspire 5741, 5733, 4551, 4741, 4740, 4771

?????????: ??? ???? ?????????
?????
???? 2000 ???

[?????? ??????? ?? ???????](#)

?????????

- ?????: ??????
- ????: Li-ion
- ??????????? ??????????: 11.1V
- ??????????: 4800mAh /65Whr
- ??????????? ??????????: 6

????????????? ?????? ??????????????:

AS10D31, AS10D3E, AS10D5E, AS10D41, AS10D51, AS10D56, AS10D61, AS10D71,
AS10D73, AS10D75, AS10D81, AS10G3E,
BT.00603.111, BT.00604.049,BT.00605.062, BT.00605.065, BT.00607.125,
BT.00607.126, BT.00607.127, BT.00606.008, LC.BTP00.123,LC.BTP00.127
31CR19/652, 31CR19/65-2, 31CR19/66-2, 934T2078F, ZQ3

????????????? ?????? ??????????:

Acer Aspire 4592 4741Z 524G50Mn 5261 5452G50Mnkk 5551G -4591 5562G50Mnss01 5735Z 5740Z-P604G32Mnss 5741-332G25Mn
5741-434G50Mn 5741G-333G32Bn 5742ZG 5896 7399 7552G-5107 7741-5137 7741G-434G50Mn 7741Z-4815 8472TG AS5741-H54D/S
AS5741-N54E/KF Aspire 4251 Aspire 4252 Aspire 4253G Aspire 4333 Aspire 4551G-P322G32Mn Aspire 4552-5078 Aspire 4552G Aspire 4625
Aspire 4733Z Aspire 4738G Aspire 4738ZG Aspire 4741G-332G32Mnsk Aspire 4741G-332G50Mn Aspire 4741G-372G50Mnkk02 Aspire
4741G-372G50Mnkk06 Aspire 4741G-5452G50Mnkk04 Aspire 4741G-5462G50Mnkk05 Aspire 4741G-5464G50Mn Aspire 4741ZG-
P622G50Mnkk03 Aspire 4743G Aspire 4750G Aspire 4771G Aspire 5251-1005 Aspire 5251-1549 Aspire 5252 Aspire 5253G Aspire 5336
Aspire 5551-2013 Aspire 5551-2036 Aspire 5551-2805 Aspire 5551-4200 Aspire 5551-4937 Aspire 5551G -4280 Aspire 5551G-P324G32Mn
Aspire 5551-P323G32Mnsk Aspire 5552G Aspire 5560g Aspire 5736Z Aspire 5741-334G32Mn Aspire 5741-334G50Mn Aspire 5741-3404

Aspire 5741-3541 Aspire 5741-433G32Mn Aspire 5741-5698 Aspire 5741-5763 Aspire 5741G-332G50Mn Aspire 5741G-334G50Mn Aspire 5741G-334G64Mn Aspire 5741G-434G64Bn Aspire 5741G-5452G50Mnck Aspire 5741G-5452G50Mnsk Aspire 5741ZG Aspire 5742G Aspire 5742Z Aspire 5750G-2312G50 Aspire 7251 Aspire 7551-2755 Aspire 7551-3068 Aspire 7551-3416 Aspire 7551-3634 Aspire 7551-5358 Aspire 7551G-5407 Aspire 7551G-5821 Aspire 7551G-6477 Aspire 7552G-5488 Aspire 7552G-6061 Aspire 7741-333G25Mn Aspire 7741-7870 Aspire 7741G-333G25Bn Aspire 7741G-333G32Mn Aspire 7741G-334G50Mn Aspire 7741G-3647 Aspire 7741G-464G64Mn Aspire 7741G-7017 Aspire 7741Z-4475 Aspire 7741Z-4633 Aspire 7741Z-4643 Aspire 7741Z-5731 Aspire 7741ZG-P604G50Mn Aspire 7741Z-P614G50Mn Aspire AS5741-H32C/SF Aspire AS5741-H54D/SF Aspire AS5741-N32C/KF Aspire AS5741-N32D/K Aspire AS5741-N54E/K H54D/LS P602G25Mn P602G50Mnkkc P604G32Mnss TM5740-X322DF TM5740-X322F TM5740-X522DOF TM5740-X522PF TM5742-X742D TM5742-X742HBF TravelMate 4370 TravelMate 4740-352G32Mn TravelMate 4740-432G50Mna TravelMate 4740-5452G50Mnssb TravelMate 4740-5462G50Mnss02 TravelMate 4740-7552 TravelMate 4740-7787 TravelMate 4740G Travelmate 4740Z Travelmate 5335 TravelMate 5340 Travelmate 5542G TravelMate 5740-332G16Mn TravelMate 5740-332G25Mn TravelMate 5740-333G25Mn TravelMate 5740-352G25Mn TravelMate 5740-372G25Mnss TravelMate 5740-434G32Mn TravelMate 5740-5092 TravelMate 5740-524G32Mn TravelMate 5740-5952 TravelMate 5740-6070 TravelMate 5740-6291 TravelMate 5740-6529 TravelMate 5740G-334G32Mn TravelMate 5740G-434G32Mn TravelMate 5740G-528G64Mn TravelMate 5740G-5452G32Mnss TravelMate 5740G-6765 TravelMate 5742-372G25Mn TravelMate 5742-373G32Mn TravelMate 5742-463G32Mn TravelMate 5742-7013 TravelMate 5742-7159 TravelMate 5742-7906 TravelMate 5742-7908 TravelMate 5742G TravelMate 5742Z-4693 TravelMate 7340 TravelMate 7740-352G32Mn TravelMate 7740-353G25Mnss TravelMate 7740G- TravelMate 7740Z- TravelMate 7740ZG-P604G50Mnss TravelMate 8472 Travelmate 8472 HF Travelmate 8472G HF Travelmate 8472T HF Travelmate 8472TG HF TravelMate 8572G TravelMate 8572T Travelmate 8572T HF Travelmate 8572TG TravelMate TM5740-X322DHBFB TravelMate TM5740-X322DOF TravelMate TM5740-X322DPF TravelMate TM5740-X322HBF TravelMate TM5740-X322OF TravelMate TM5740-X322PF TravelMate TM5740-X522DF TravelMate TM5740-X522DHBFB TravelMate TM5740-X522DPF TravelMate TM5740-X522F TravelMate TM5740-X522HBF TravelMate TM5742-X732DF TravelMate TM5742-X732DHBFB TravelMate TM5742-X732DOF TravelMate TM5742-X732F TravelMate TM5742-X732HBF TravelMate TM5742-X732OF TravelMate TM5742-X732PF TravelMate TM5742-X742DF TravelMate TM5742-X742DHBFB TravelMate TM5742-X742DOF TravelMate TM5742-X742F TravelMate TM5742-X742OF TravelMate TM5742-X742PF X522OF X732DPF X742DPF [EMACHINES] G530 G730 G730G G730ZG [GATEWAY] NS41i NS51i NV49C13C NV49xx NV50A NV51B NV53A11u NV55C NV59C NV73A NV79 [PACKARD BELL] EasyNote NM84 EasyNote NM85 EasyNote NM86 EasyNote TS11HR EasyNote TS13HR EasyNote