

????????? Hi-Black MX80 ??? LX FX



HB-S015019



????????? Hi-Black (HB-S015019) ??? ?????????? ?????????? Epson LX/ FX-800/ 300/ 400, MX-80, ??????

?????????: ??? ???? ??????????
?????
????? 150 ???

[??????? ??????? ?? ???????](#)

?????????
??? ??????????????:
?????????? ??????????

?????? ??????????????:
Epson

??? ??????????????:
?????????? ??????????

??? ??????????????????:
C13S015019BA, C13S015637BA

??? ??????:

???????????

??? ???????????? ??????????:

??????????

????????? ?????? (?????):

Hi-Black

????:

??????

?????????????:

????? 10 ?.

?????? ??????????:

Epson FX-80, Epson FX-85, Epson FX-100, Epson FX-105, Epson FX-800, Epson FX-850, Epson FX-870, Epson FX-880+, Epson FX-1180, Epson LX-300+, Epson LX-400, Epson LX-800, Epson LX-850, Epson RX-100, Epson MX-100, Epson MX-80